Assembly Instructions of MG WallMaster

Procedures:

1. The Gland Plates to the Top & Bottom Panel

The Top & Bottom Panel can be distinguished as follows.

2. The Basic Side Frame (Left & Right)

Correctly insert the Side Frames to the Bottom Panel

3. The Back Panel

4. The Top & Bottom Stiffener

The installation of Top Stiffener is the same way as the bottom one

5. The 19” Vertical Mounting Angels

6. The Top Panel

7. The Side Panels

8. The Front Door

Front Door Lock Bracket

Nylon Bush

Foams stick to the inner side on the Front Door top & bottom

Complete Unit